

## Redcat with Hear and Learn PowerMount bracket

### MOUNTING INSTRUCTIONS

# PowerMount


Add a Media Connector.  
Control Redcat from Teachers work station




#### Finished look of Redcat with PowerMount system.

Redcat is for rooms up to 100m<sup>2</sup> floor space. Redcat is mounted at approx 1600 mm from base of Redcat to floor, and mounted as close as possible to the middle of the longest wall of the classroom, and not on the front/teaching wall.


POWERMOUNT FRONT VIEW



REDCAT BACK VIEW




POWERMOUNT TOP VIEW




REDCAT MOUNTED TOP VIEW

Transformer in position in PowerMount



REDCAT SIDE VIEW MOUNTED TO WALL



#### Wall mounting your Redcat?

Using the PowerMount bracket system hides the GPO power point and 3.5 mm plug cable wallplate behind the Redcat. For a Redcat manual and help go to [hearandlearn.com.au/product/redcat-point-to-pair](http://hearandlearn.com.au/product/redcat-point-to-pair) or use the QR code.

